

Raised Bed

Parts List

BOARDS

ALUMINUM RAISED BED CORNERS

CORNER CAPS

3/4" STAINLESS STEEL PHILLIPS SCREWS

IN-LINE RAISED BED CONNECTORS (2' x 12', 3' x 12', and 4' x 12' sizes only)

Tools Required

Screw gun with Phillips screwdriver tip

Rubber mallet or hammer

Assembly

1. Locate a level area and prepare the ground for planting. If you are installing the raised bed on a lawn, we recommend removing the sod and loosening the soil with a shovel or spade to a depth of 6".

2. Notice how the BOARDS have both a smooth side and a rough side. Choose which side you want facing out, then place the BOARDS on their sides to form a square or rectangular bed. Slide the ends of the BOARDS into the four ALUMINUM RAISED BED CORNERS (Fig. 1). **NOTE:** For the 12' models, assemble the long sides of the bed by inserting the 6' BOARDS into the IN-LINE CONNECTORS (Fig. 2).

Figure 1





Figure 2: 12' Raised Beds



3. Make sure all of the BOARDS are fully seated and level with the bottoms of the ALUMINUM RAISED BED CORNERS and IN-LINE CONNECTORS, if applicable. Insert SCREWS through all holes in the ALUMINUM RAISED BED CORNERS and IN-LINE CONNECTORS and tighten to secure.

4. Insert a black CORNER CAP into the top of each ALUMINUM RAISED BED CORNERS and IN-LINE CONNECTOR. Your **Raised Bed** assembly is now complete! We recommend using a mixture of garden soil and plenty of organic matter, such as compost, for best results.

For a handy **Soil Volume Calculator**, and advice on how to grow in raised beds, visit us at www.gardeners.com